Installation Instructions for the

## **File Drawer System**

Part # RAS-SMFD-52, RAS-LGFD-52







## Instructions

- 1. Measure drawer inside dimension, front to back
- 2. Using this dimension, cut Metal Runners (C) with hacksaw
- 3. Place End Supports (A) into drawer
- 4. Press fit Metal Runners (C) into End Supports (A)
- 5. Using screws provided, attach End Supports (A) to drawer box walls.
- 6. Attach T-Rod (B) to Metal Runners (C) for legal and letter size storage.

Questions? Call our Customer Service Specialist at 800-626-1126 www.rev-a-shelf.com



